

Instromet Wind switch selection chart

Wind switch model	Part number	Datasheet	power supply			5A Relay	Wind Speed	Wind Direction	Activation timers	wind speed Display	Wind sensor
			mains - 240V	12V DC	24V AC						
Speed only	353 0001 001	Datasheet	yes	yes		yes	yes		yes		Basic
Speed only	353 0002 001	Datasheet	yes	yes		yes	yes		yes		Pro
Speed only with display	353 0001 002	Datasheet	yes	yes		yes	yes		yes	yes	Basic
Speed only with display	353 0001 003	Datasheet	yes	yes		yes	yes		yes	yes	Pro
12V Speed only	353 0006 001	Datasheet		yes		yes	yes		yes		Basic
12V Speed only	353 0007 001	Datasheet		yes		yes	yes		yes		Pro
speed and direction	353 0003 001	Datasheet	yes	yes		yes	yes	yes	yes		Basic
speed and direction	353 0004 001	Datasheet	yes	yes		yes	yes	yes	yes		Pro
speed and direction	353 0008 001	Datasheet	ACA	yes	yes	yes	yes	yes	yes		Basic
speed and direction	353 0008 002	Datasheet	ACA	yes	yes	yes	yes	yes	yes		Pro

Notes

ACA = AC Adaptor

All wind speeds are in mph

Basic wind sensor = 2 x sintered bronze bearings

Pro wind sensor = 1 x sintered bronze bearing & 1 x ball race bearing.